

SPA FROG BROMINE CARTRIDGE SYSTEM

| WHAT TO DO |
|--|
| Balance pH and Alkalinity Set Spa Frog to 4 or 5 100g of Non-Chlorine Shock (4 Caps) 60mL of Metal Guard (6 Caps) |
| Set Spa Frog to 2 or 3 ½ - 1 Cap of Non Chlorine Shock |
| Test the water and balance according to your test strips 100g of Non Chlorine Shock (4 Caps) 30mL of Metal Guard (3 Caps) |
| Remove Filter Cartridges and clean with a hose or a cartridge cleaner solution |
| Prepare hot tub for draining by removing and soaking filter cartridges in a cartridge cleaner solution or purchase new filters Add 250mL of Whirlpool Rinse and run the jets for 2 hours. Drain and refill the hot tub Replace Nature2 Clarifier Spa Stick |
| RANGES |
| 3-5ppm |
| 80-120ppm |
| 0-500 ppb |
| |

Please Note:

Calcium

рΗ

The level the Spa Frog has to be set will be bather load dependent. The more people and longer the hot tub is in use, the higher the Spa Frog has to be set level will be.

7.2 - 7.8

100-300 ppm

A spa frog should last 1 – 2 months.

All chemicals should be poured near the filters for even distribution, with the jets on high or by activating a clean cycle. All air jets should be turned off.

Always wait 30 minutes to use the hot tub after applying chemical treatments. A longer wait may be required if bromine or pH Down have been added.



