


Tristar VS 950 Omni

PUMP SERIES REPLACEMENT PARTS

Parts for Pump Models: HL32950VSP




Ref. No.	Part No.	Description	Ctn. Qty.
1	SPX3200UNKIT	Union Connector Kit (Includes Union Nut, Union Connector, Union Gasket – 2 ea.)	10
2	SPX3200UG	Union Gasket	100
3	SPX3200A	Pump Strainer Housing, 2" x 2 1/2" with Drain Plugs, Threaded Style	1
4	SPX3200DLS	Strainer Cover Kit (Includes Strainer Cover, Lock Ring, O-Ring)	10
	SPX3200DLSB	Strainer Cover Kit (Biguanide Sanitizer Applications Only; NOT Pressure Testable)	10
5	SPX3200S	Strainer Cover O-Ring	50
6	SPX3200M	Strainer Basket	2
7	SPX3200Z8	Diffuser Screw	50
8	SPX4000Z1	Diffuser O-Ring	50
9	SPX3200B3	Diffuser	5
10	SPX3200Z1	Impeller Screw	50
11	SPX3021R	Impeller Ring	50
12	SPX3220C	Impeller with Impeller Screw	10
13	SPX4000SAV	Viton® Shaft Seal Assembly	10
14	SPX3200T	Housing O-Ring	50
15	SPX3200E	Seal Plate	5
16	SPX3200Z211	Housing Insert/Seal Plate Spacer Kit	50
17	SPX3200Z3	Housing Bolt	50
18	SPX3200Z5PAK4	Motor Bolt Kit	50
19	SPX4000FG	Drain Plug with O-Ring	50
20	SPX3200GA	Bracket, Motor Support	5
21	SPX3200WF	Riser Base Aligns with Pentair® WhisperFlo® Ports	1
21	SPX3200SR	Riser Base Aligns with Sta-Rite® Max-E-Pro™, Max-E-Glas®, Dura-Glas® and Dura-Glass II® Ports	1
22	SPX3200Q	Adapter-Motor Support	100
23	SPX3400Z1ECM	Motor Assembly	1
24	SPX3400FAN	Motor Fan Shroud	5
25	SPX3400DR	Motor Drive (Includes Digital Control Interface)	1
26	SPX3400DR4	Motor Drive Display Cover	5
27	SPX3400DR2	Motor Drive Wiring Cover	5
28	SPX3400LCD	Digital Control Interface Assembly	1
29	HLXDCOVER	Sun Cover Replacement	1
30	HLXDLCD	LCD Disp Replacement	1
31	HLXDSPCASE	Case Replacement	1
32	HLX485RELAY	Replacement RS485 Relay	1
33	HLXJBOX	Replacement Jbox	1
34	HLXHIOPCB	OmniHub PCB	1
—	HLXHW5PK	OmniHub Hardware - Not Shown (5 pack)	1
—	HLXWHIP6	Omni 6 ft. Whip - Not Shown	1
—	SPX3400DRKIT	Wall Mount Kit for Digital Control Interface	5
—	SPX3400DRCBL	Wall Mount Display Cable	5
—	SPXHKIT100	H-KIT Quick Pump Repair (Includes items 5, 8, 13, 14 and Jack's Lube)	10
—	GLX-ACT-CONN	Actuator Connector	100
—	HLH485RELAY	Omni RS485 Smart Relay	1
—	HLX485100	RS485 100 ft. Extension	1
—	HLX485200	RS485 200 ft. Extension	1
—	HLXRLYLABL	Replacement Relay Label	1

Tristar® VS 900 Omni

PUMP SERIES REPLACEMENT PARTS

Parts for Pump Models: HL32900VSP



Ref. No.	Part No.	Description	Ctn. Qty.
1	SPX3200UNKIT	Union Connector Kit (Includes Union Nut, Union Connector, Union Gasket – 2 ea.)	10
2	SPX3200UG	Union Gasket	100
3	SPX3200A	Pump Strainer Housing, 2" x 2 1/2" with Drain Plugs, Threaded Style	1
4	SPX3200DLS	Strainer Cover Kit (Includes Strainer Cover, Lock Ring, O-Ring)	10
5	SPX3200DLSB	Strainer Cover Kit (Biguanide Sanitizer Applications Only; NOT Pressure Testable)	10
6	SPX3200M	Strainer Basket	2
7	SPX3200Z8	Diffuser Screw	50
8	SPX4000Z1	Diffuser O-Ring	50
9	SPX3200B3	Diffuser	5
10	SPX3200Z1	Impeller Screw	50
11	SPX3021R	Impeller Ring	50
12	SPX3210C	Impeller with Impeller Screw	10
13	SPX4000SAV	Viton® Shaft Seal Assembly	10
14	SPX3200T	Housing O-Ring	50
15	SPX3200E	Seal Plate	5
16	SPX3200Z211	Housing Insert/Seal Plate Spacer Kit	50
17	SPX3200Z3	Housing Bolt	50
18	SPX3200Z5	Motor Bolt	50
19	SPX4000FG	Drain Plug with O-Ring	50
20	SPX3200GA	Bracket, Motor Support	5
21	SPX3200WF	Riser Base Aligns with Inlet Port of Pentair® WhisperFlo® Pump	1
21	SPX3200SR	Riser Base Aligns with Sta-Rite® Max-E-Pro™, Max-E-Glas®, Dura-Glas® and Dura-Glass II® Ports	1
22	SPX3200Q2	Adapter-Motor Support	100
23	SPX3400DR4	Motor Drive Display Cover (Cover only)	5
24	HLXDCOVER	Sun Cover Replacement	1
25	HLXDLCD	LCD Disp Replacement	1
26	HLXDSPCASE	Case Replacement	1
27	HLX485RELAY	Replacement RS485 Relay	1
28	HLXJBOX	Replacement Jbox	1
29	HLXHIOPCB	OmniHub PCB	1
—	HLXHW5PK	OmniHub Hardware - Not Shown (5 pack)	1
—	HLXWHIP6	Omni 6 ft. Whip - Not Shown	1
—	SPX3200LCD	Digital Control Interface Assembly	1
—	SPX3400DRKIT	Wall Mount Kit	5
—	SPX3400DRCBL	Wall Mount Display Cable	5
—	SPX320Z21VSPE	Power End Assembly (Includes parts #7-15 and 18, Motor, Drive and Display)	1
—	HLH485RELAY	Omni RS485 Smart Relay	1
—	HLX485100	RS485 100 ft. Extension	1
—	HLX485200	RS485 200 ft. Extension	1
—	HLXRLYLABL	Replacement Relay Label	1